



MASTER

CE







USER AND MAINTENANCE BOOK

GB

Edition 14 - Rev. 2

MF 30 DV

TECHNICAL DATA

	~110 V / 50Hz	~220-240 V / 50Hz
	300 / 261 W	324 / 278 W
	2,92 / 2,54 A	1,4 / 1,21 A
IP	20	
	30" / 750 mm	
	1150 / 950 RPM	1250 / 1150 RPM
	13680 / 12300 m ³ /h	16200 / 13680 m ³ /h
	92 x 26 x 93 cm	
	16 kg	

PARAGRAPH SUMMARY

1...	IMPORTANT SAFETY INSTRUCTIONS
2...	OPERATING INSTRUCTION
3...	MAINTENANCE

▶▶ IMPORTANT SAFETY INSTRUCTIONS

CAUTION: READ AND FOLLOW ALL INSTRUCTIONS BEFORE OPERATING THIS FAN.

Use the fan only as described in this manual. Misuse may cause a fire or an electrical shock.

- ▶ 1. Do not operate the fan with a damaged cord or plug, after the fan malfunctions, has been dropped or damaged.
- ▶ 2. Close supervision is necessary when this fan is used near children, the elderly and pets.
- ▶ 3. Always turn the fan off after use, before cleaning, or moving location.
- ▶ 4. Do not insert fingers or other objects into the fan guard.
- ▶ 5. Do not operate the fan in areas where petrol, paint or other flammable liquids are used or stored.
- ▶ 6. Do not place the fan near an open flame, cooking or heating appliance, or hot surface.
- ▶ 7. This fan is not intended for use in wet or damp locations. Never locate the fan in an area where it may fall into a bath or other water container.
- ▶ 8. Always use on a dry, level surface.
- ▶ 9. Do not let the power cord hang over the edge of a table or counter.
- ▶ 10. Arrange the cord away from an area where it may be tripped over.
- ▶ 11. Never place the power cord under a carpet or rug.
- ▶ 12. To disconnect from the power supply, grip the plug and pull from the power socket. Never pull by the cord.
- ▶ 13. This fan should not be operated outside.
- ▶ 14. Do not hang or mount the fan on a wall or ceiling.
- ▶ 15. Do not operate without fan guard properly in place.
- ▶ 16. If the power cord is damaged, it must be replaced by the manufacturer or a qualified service engineer to avoid any risks to safety.

▶▶ OPERATING INSTRUCTION

To adjust airflow upward or downward: Tilt the fan head to the desired angle by hand easily Speed Control: Rotate SWITCH to LOW or HIGH speeds for respective air velocity.

- ▶ 1. After continuous operation, it is normal for the motor to feel warm when touched.
- ▶ 2. This fan features an overheat safety cut-out device, which will automatically shut the fan off should it overheat for any reason. If this happens immediately unplug the fan from the power socket.

▶▶ MAINTENANCE

- ▶ 1. Before cleaning turn the fan off and unplug from the power supply.
- ▶ 2. To clean the fan use a soft cloth to wipe off any dust. If the fan is very dirty use a damp cloth and wipe dry. Do not use any cleaning detergents, sprays or other chemicals, as they will damage the plastic.
- ▶ 3. Store the fan in the original packaging in a ventilated dry area.

- ▶ 4. The motor bearings are permanently sealed and do not require additional lubrication.

WARNING

Do not operate the fan with a damaged cord or plug, after the fan malfunctions, has been dropped or damaged.

Do not use extension cords with this product!

To reduce the risk of fire or electrical shock, do not use the product with a solid state speed control device.

CAUTION

Automatically operated device-To reduce the risk of injury disconnect from power supply before servicing.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

EC DECLARATION OF CONFORMITY

MCS Central Europe Sp. z o.o.
ul. Magazynowa 5a, 62-023 Gądko, Polska

declared that appliances

MF 30 DV

conform to directives


2006/95/EC; 2004/108/EC

and norms

**EN 60335-1, EN 60335-2-80, EN 62233,
EN 55014-1, EN 55014-2, EN61000-3-2, EN 61000-3-3**

Gądko, 16-01-2013 / CE-13

Stefano Verani



CEO MCS Group

GB - Disposal of your old product

- Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.
- When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
- Please inform yourself about the local separate collection system for electrical and electronic products.
- Please act according to your local rules and do not dispose of your old product with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.

